

for M.G. Magnette ZA & ZB Saloons

Series from Oct 53 - Jan 59

General Information

Maximum trailer weight, see vehicle manufacturer's specification. Max.Nose Wt. 50kg Tow-Bar Wt. 11kg

BSAU113a 50mm Ball Centre Height is between 350mm and 420mm when the vehicle is laden.

Spanners: 16mm, 17mm, 18mm, 19mm, 24mm AF. Drills: 10mm. Fitting Time about 1.5 hrs

MATERIALS

- A 1 off Cross Bar 1056mm 60x40x4mm RHS with 130mm end plates & 210mm extension tube with Hitch Mounting drilled to BSAU114a to meet a height within BSAU113a
- B 2 off Side Plates 170mm 130x6mm Flat
- C 1 Clamp Plate 130mm 25x6mm Flat
- D 2 off 10 x 30mm H.T. bolts nuts & shakeproof washers
- E 2 off 10 x 75mm " " " " "
- F 2 off 10 x 90mm " " " " "
- G 4 off ½" x 1¼" " " " " "
- H 2 off 16 x 45mm " " " " "
- J 4 off Washers 40mm x 10mm hole

FITTING INSTRUCTIONS

1. Read the WATLING TOWING BRACKET INFORMATION AND MAINTENANCE SHEET AND THE FITTING GUIDE. Clear the boot floor, remove the spare wheel and number plate, remove the 4 bumper support arm bolts leaving the bumper in place.
2. Fix the Side Plates B to the outside of the chassis with 2 bolts F at the rear and 2 bolts E at the front using washers J inside. Fix Cross Bar A to B with 4 bolts G.
- NOTE:** It may be necessary to reposition the rear exhaust hanger to allow clearance for the Cross Bar A.
3. Drill 2 off 10mm hole up through the centre plate on A into the floor pan. Fix with 2 bolts D using Clamp Plate C.
4. Fix your hitch to A with 2 bolts H. Tighten all bolts to the correct torque including bumper bracket and chassis bolts, see the WATLING TOWING BRACKET INFORMATION AND MAINTENANCE GUIDE. Replace trim, spare wheel, tool kit and boot contents. Refit the number plate onto the bumper with self tapping screws.

