



NTG Motor Services Limited

282 - 284 Bramford Road Ipswich Suffolk IP1 4AY

Tel: ++44 (0)1473 - 406031 & 406032

Fax: ++44 (0)1473 - 742087 Email: sales@mgbits.com

www.mgbits.com

www.bmcfarina.com

Directors: M.Green P.Banyard

Company Reg.No. 1262476

V.A.T.Reg. No. 289 5422 17

L344A Fitting Tips

- Remove one lead from your distributor cap and spark plug.
- Cut a length of lead to the same length as one removed.
- One end, screw a new cap into the lead (inside is copper core so it will make its own thread and contact)



- The other end of the cable needs to be stripped back slightly exposing the metal strands.
- Attach Acorn nut and copper washer.



- Peen over the strands of wire to hold washer in place and make contact with the distributor cap and insert into cap



- Insert into Distributor cap replacing removed old cable - This is now ready to attach to corresponding spark plug.